

Installation Instructions

Trailer Hitch Kit, GVW 200 lbs.

Part No. 5600031

For Ferris IS500Z, IS1500Z & IS4500Z Series; Snapper Pro S50X/XT, S150X/XT, & S200X/XT Series; Simplicity Citation Series

Kit Contents:

Part No.:	Qty:	Description
5400535A	1	Plate, Hitch
5400534A	1	Plate, Backing Mount
5100067	1	Decal, Warning, Trailer, 200 GVW
5025013X20	4	Bolt, 3/8-16 X 2-1/2"
5025013X10	4	Bolt, 3/8-16 X 1-1/4"
5025394	4	Nut, 3/8-16 Nylock Flange

WARNING

Before beginning any service work turn off the PTO, set the parking brake, turn off the ignition, and disconnect the spark plug wire(s).

Ferris & Simplicity Models

1. Park machine on a flat, level surface and engage the parking brake. Disengage the PTO switch, turn off the engine and remove the key from the ignition.
2. If the engine is hot, allow sufficient time for the muffler to cool to prevent a burn injury during installation.
3. Install the 3/8-16 X 2-1/2" bolts (B, Figure 1) through the hitch plate (A).
4. Install the hitch plate onto the bumper with the bolts in between the bottom and middle bumper tubes.
5. Install the back plate (C) and loosely secure with the 3/8-16 nylock flange nuts (D).
6. Center the hitch plate side-to-side on the bumper and tighten the hardware securely.

Snapper Pro Models

1. Park machine on a flat, level surface and engage the parking brake. Disengage the PTO switch, turn off the engine and remove the key from the ignition.
2. If the engine is hot, allow sufficient time for the muffler to cool to prevent a burn injury during installation.
3. Install the 3/8-16 X 1-1/4" bolts (B, Figure 2) through the hitch plate (A).
4. Install the hitch plate onto the bumper with the bolts in the middle two slots of the center column as shown in Figure 2.
5. Install the back plate (C) and loosely secure with the 3/8-16 nylock flange nuts (D).
6. Center the hitch plate side-to-side on the bumper and tighten the hardware securely.




Figure 1. Install Hitch Kit (Ferris & Simplicity)

- A. Hitch Plate
B. 3/8-16 X 2-1/2" Bolts (4X)
C. Back Plate
D. 3/8-16 Nylock Flange Nuts (4X)




Figure 2. Install Hitch Kit (Snapper Pro)

- A. Hitch Plate
B. 3/8-16 X 1-1/4" Bolts (4X)
C. Back Plate
D. 3/8-16 Nylock Flange Nuts (4X)